



DIAMOND PRODUCTS

CHAINSAW HCH50 PARTS LIST





Product description

Important information on the Chain saw **HCH50**

Main components




Fig. 1-1 Main components

- 1 Bar
- 2 Chain
- 3 T-handle
- 4 Valve block
- 5 Cutting mandrel
- 6 Chain guard
- 7 Operating handle with manual starter8 Coupling FD (flow)
- 9 Hose stem (water) 10 Nipple FD (return)

Accessories

- Flow divider / Pressure limiter 40 l/min, 140 bar
- Pressure control valve 140 bar

Scope of supply

Complete chain saw system HCH50***:

- Chain saw HCH50***
- Carrying case HCH50***
- Tool kit HCH50***
- Operating Instructions / Spare parts list

6. Drive wheel assembly guide

Tool kit comprises:




Fig. 1-2 Tool kit

Plastic tool bag
 Chain spray
 Allen key SW 5
 Ring/open ended spanner SW 10
 Ring/open ended spanner SW 19
 Part No. 973791
 Part No. 973781
 Part No. 973781
 Part No. 973784

Part No. 962724

Design and function

Design

The Chain saw HCH508*** is comprised the following components.

- · Chain saw unit
- TYROLIT Hydrostress AG bar
- TYROLIT Hydrostress AG diamond chain

Safety component:

· Chain guard




Fig. 1-3 Chain saw HCH50 design

- 1. Chain saw unit
- 2. Bar
- 3. Diamond chain
- 4. Chain guard

Function

The overall function of the Chain saw HCH508*** remains exactly the same. The Chain saw HCH508*** is powered by a hydraulic drive assembly. The chain is driven by the hydraulic motor incorporated into the chain saw unit. The driven chain is inserted into the material to be cut.

Component description

Chain saw unit

Design




Fig. 1-4 Chain saw unit

- 1. Operating handle with manual starter
- 2. Water level housing
- 3. Drive wheel
- 4. Fitting aid (chain-engraving)
- 5. Cutting mandrel
- 6. Hydraulic connection
- 7. Water connection
- 8. Name plate
- 9. Valve block
- 10.Chain guard
- 11.T-handle

Function

The chain saw unit is the central component of the Chain saw HCH50. The chain saw unit incorporates the drive motor and the operating handle and T-handle for using the HCH508***. The unit along with its valve block and the hydraulic and water connections also constitutes the interface with the power source (drive assembly).

DIAMOND PRODUCTS AG bar

Design




Fig. 1-5 Bar

- 1. Water inlet
- 2. Chain guide
- Assembly bore hole for chain tensioner
- 4. Assembly opening
- 5. Reversing wheel

Function

The bar is securely fixed to the chain saw unit. The chain runs and is guided on the bar. The bar provides lateral support for the chain. The cutting pressure is absorbed via the bar.



Information

The bar serves solely to guide the diamond chain. Never use the bar as a lifting tool or a crow bar.

How to use the spare parts list

The spare parts list is not intended as instructions for assembly or dismantling work. It is exclusively intended to help you to quickly and easily find spare parts, which can then be ordered at the address below.

Safety regulations

Danger

The assembling or dismantling of modules can involve risks which are not identified in this spare parts list.



The use of this spare parts list for assembly or dismantling purposes is strictly forbidden. For assembly or dismantling tasks it is essential to only follow the corresponding descriptions in the operating manual.

If this regulation is not heeded injuries may be incurred which in the worst case can also be fatal.

Ordering



Information

To avoid incorrect deliveries you should check the order details for correctness and completeness (see under ordering details) prior shipment.

You should ensure that the delivery address is given in full.

Order address:


Diamond Products

333 Prospect Street Elyria, Ohio USA Toll Free (800) 321-5336 Phone (440) 323-4616 Fax (440) 323-8689 e-mail: dp@diamondprod

e-mail: dp@diamondproducts.com www.diamondproducts.com

Spare Parts List

Ordering details




When spare parts are ordered we need the following details:

- Machine type according to nameplate (e.g. HCH50***)
- Machine number according to nameplate (e.g. 10977640)
- Machine index according to nameplate (e.g. 000)
- Spare part number according to the spare parts list (e.g. 10977345)

For orders, questions and information please contact your responsible branch office.


$\frac{\textbf{3401281 Assembly}}{\underline{\textbf{View 1}}}$





3401281 Parts List


		BOM Table	2
ITEM	PART NO.	QTY.	DESCRIPTION
1	3401398	1	Valve Body HCH50
2	3401399	1	Hyd. Motor GR2 8CCM - HCH50 Saw
3	3401408	1	Chain Saw Frame Assy, HCH50
4	3401013	1	Tensioning Nut
5	3401018	2	Bolt to Chain Bar
6	3401015	1	Tensioning Screw
7	3401014	1	Nut, Counter
8	3401017	1	Chain Bar Plate
9	3401287	1	Chain Guard
10	3402177	1	Cutting Mandrel
11	3401010	1	Handle (Weldment)
12	3401392	1	Clamp Piece
13	3401152	1	Screw M8 LEFT x 22
14	3401376	1	Drive Sprocket, Chain Saw
15	3401407	1	Seal Back Up Ring
16	3401011	1	Spirit Level
17	3401016	1	Set Screw, M6 x 6
18	3400549	2	Cap Screw, Soc. Hd., M4 x 35
19	3402011	1	Cap Screw, Soc. Hd., M6 x 16
20	2900554	3	Cap Screw, Soc. Hd., M6 x 20
21	2900243	4	Cap Screw, Soc. Hd., M8 x 20
22	2903249	1	Cap Screw, Soc. Hd., M8 x 80
23	2900666	4	Cap Screw, Soc. Hd., M10 x 80 Low Head
24	2900482	2	Hex Nut, M12
25	2900544	3	Cap Screw, Hex Hd., M6 x 12
26	2900765	3	Lock Washer, M6 Split
27	2900311	2	Cap Screw, Hex Hd., M6 x 25
28	2903233	4	Washer M8 15/8.4/1.6
29	3403010	3	M12 Flat Washer
30	2704957	1	Ring, Retaining, Int 30mm
31	3401400	2	O-Ring 8.0x2.0 N70
32	3401295	1	Seal, Motor Shaft
33	3400837	1	Seal,CSF40 Sprocket
34	3401418	1	Grip, Handle
35	3401384	1	Rear Handle Kit
36	3201739	1	1/4"M. Pipe to 3/8" Hose Barb 45 Deg
37	1800169	1	DP S/N Nameplate
38	3401417	1	Screw, Locking
39	3401416	2	O-ring, M2.62 x 66.35
40	2900053	2	Rivet, 3/32" Dia.

3401281 Assembly <u>View 2</u>













ITEM	PART NO.	QTY.	DESCRIPTION
1	6063039	1	12" Saw Bar







ITEM	PART NO.	QTY.	DESCRIPTION
1	6060261	1	16" Saw Bar





ITEM	PART NO.	QTY.	DESCRIPTION
1	6060260	1	20" Saw Bar





ITEM	PART NO.	QTY.	DESCRIPTION
1	6063038	1	24" Saw Bar

<u>Notes</u>

Notes

EQUIPMENT AND PARTS WARRANTY

Diamond Products warrants all equipment manufactured by it against defects in workmanship or materials for a period of one (1) year from the date of shipment to Customer.

The responsibility of Diamond Products under this Warranty is limited to replacement or repair of defective parts at Diamond Products' Elyria, Ohio factory, or at a point designated by it, of such parts as shall appear to us upon inspection at such parts, to have been defective in material or workmanship, with expense for transportation and labor borne by Customer.

In no event shall Diamond Products be liable for consequential or incidental damages arising out of the failure of any Product to operate properly.

Integral units such as engines, electric motors, batteries, transmissions, Etc., are excluded from this Warranty and are subject to the prime manufacturer's warranty.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, AND ALL SUCH OTHER WARRANTIES ARE HEREBY DISCLAIMED.



333 Prospect Street, Elyria, Ohio 44035 (440) 323-4616 • (800) 321-5336 • Fax (440) 323-8689 www.diamondproducts.com